



Coffee Urn Directions

1. Remove top, basket, and wand from coffee urn.
2. Fill with cold water to desired line depending on the amount of coffee you wish to make.
3. Replace wand and basket back inside the urn.
4. No paper filter is needed for the machine. Use the basket as your filter and pour dry coffee inside basket.
5. Replace top and plug into a dedicated 20 amp outlet.
6. Allow one hour for brewing time.
7. Rinse out all instruments when finished. Rinse off extra coffee debris. Do not clean the coffee maker.

Important-Use a dedicated 20 amp outlet!

This unit draws more amperage than any appliance in your kitchen.

Measurements

60 cups	58-61 tablespoons
50 cups	48-51 tablespoons
40 cups	38-41 tablespoons
30 cups	28-31 tablespoons
20 cups	18-21 tablespoons
10 cups	8-11 tablespoons

*The amounts given are indicative only and be adjusted according to personal taste.

Note: 16 Tablespoons = 1 cup