



Events

PARTY & TENT RENTALS



Charcoal Grill Instructions

1. The delivered grill will come to you pre-assembled. If you pick up the grill, you will need to put the legs back on to the base by sliding them on and inserting the pins to hold them in place.
2. Remove the grill top and line the base with aluminum foil which will help to reflect the heat and make it easier to clean up.
3. Place 3 evenly spaced piles of charcoal in the base, using a total of approximately 20 pounds. Use lighter fluid to ignite the charcoal following manufacturer instructions.
4. After approximately 30 to 40 minutes, the coals will be ready for cooking. Spread the coals evenly in the base.
5. Use cooking oil to coat the grill top to prevent food from sticking and place grill on base at desired height.
6. When food is cooked, remove the grill top to prevent excess food and grease from burning on.
7. When the coals are cool, roll them up inside the foil and discard.

Important Reminders:

Never pour water on coals to extinguish. This will cause the base to warp.